Mr.SLIM

R410A. A control. Five Wire Adapter Operation.



Pin 3 will give a permanent 12vDC Output. Pins 5 and 3 for Alarm Output Pins 4 and 3 for Run Output Note that colours above may change. Use pin numbers for accuracy. X1 and X2 – field supply relays

