


7.1.11 DX-Interface



(*) For installation.


All measurements are in mm.

7.2 Operation and service space


7.2.1 RCI-(1.0-6.0)FSR1 - 4-way cassette

◆ Operation space

Single installation



Combined installation



1. Drain piping connection.
2. Walls close to the unit.
3. Service access door for unit inspection and maintenance access.
4. Piping connection.