




PUZ-M100VKA(-ET).TH
 PUZ-M125VKA(-ET).TH
 PUZ-M140VKA(-ET).TH

PUZ-M100YKA(-ET).TH
 PUZ-M125YKA(-ET).TH
 PUZ-M140YKA(-ET).TH

Unit: mm




4 PIPING-WIRING DIRECTIONS

Piping and wiring connections can be made from 4 directions: Front, Right, Rear and Below.


3 FOUNDATION BOLTS

Please secure the unit firmly with 4 foundation (M10) bolts. (Bolts and washers must be purchased locally)




2 SERVICE SPACE

Dimensions of space needed for service access are shown in the below diagram.



1 FREE SPACE (Around the unit)

The diagram below shows a basic example. Explanation of particular details are given in the installation manuals etc.



Example Of Notes

- ① ··· Refrigerant GAS pipe connection (FLARE) (Ø5.81 (5/8FI))
- ② ··· Refrigerant LIQUID pipe connection (FLARE) (Ø5.2 (3/8F))
- ※1 ··· Indication of STOP VALVE connection location.

Piping Knock-Out Hole Details

PUZ-M200YKA.UK
PUZ-M250YKA.UK

Unit: mm

