



MXZ-2D33VA MXZ-2D40VA MXZ-2D53VA MXZ-2D53VAH

Unit: mm




MXZ-3D54VA MXZ-3D68VA




1.Installation space


Note : Leave front and both sides free of obstruction.




Note : Leave front and overhead free of obstruction.




Note : Leave rear, overhead and both sides free of obstruction.



2. Service space




Unit: mm




1.Installation space


Note : Leave front and both sides free of obstruction.




Note : Leave front and overhead free of obstruction.



Note : Leave rear, overhead and both sides free of obstruction.






2. Service space




MXZ-4D83VA MXZ-5D102VA

Unit: mm




1.Installation space


Note : Leave front and both sides free of obstruction.



Note : Leave front and overhead free of obstruction.



Note : Leave rear, overhead and both sides free of obstruction.



2.Service space

