



## MXZ-2HA40VF MXZ-2HA50VF

Unit: mm (inch)




--

Unit: mm (inch)




## 1.Installation space


Note : Leave front and both sides free of obstruction.



## 2. Service space



Note : Leave front and overhead free of obstruction.



Note : Leave rear, overhead and both sides free of obstruction.

